


プラス棒

10 30		4方	3方	上部	なし
-------	---	----	----	----	----